


RS41 Spreader



Accessories for Shindaiwa products can be found at:
www.shindaiwa-usa.com/products/accessories.aspx

PARTS LIST	2
PARTS LIST	3

PARTS LIST



NO.	PART NUMBER	QTY.	DESCRIPTION
1	P14508-1SH	1	Hopper Assembly
2	P14455-1	1	+Rate Cam & Chute Assembly
3	P14454-1	1	+Shutoff Plate
4	P15849	1	Impeller Assembly
5	P15837	1	Frame Assembly
6	P136191-03	2	Legs
7	P15842	1	Axle
8	P14634	1	Axle Collar
9	P14951	2	Axle Bushings
10	P15833	1	Impeller Shaft Bearing
11	P13625-1	1	Axle Gear
12	33117	1	Agitator
13	P14939-1	2	Drive & Free Turning Wheels
14	P136131-03	2	Handle Braces
15	P145132-03	1	Handle Tube
16	P13634-2	1	T-Handle Assembly
17	P14462	1	Control Knob Spring
18	P146151	1	Control Knob & Wire Ass'y.
19	P13643-1	1	Wire Retaining Clip
20	P13623	1	Gear Cover Assembly
21	P15880	1	Fastener Package
22	P15209	1	Hopper Cover
23	P15264	2	Handle Grip
24	P16235	1	Hopper Label