


RS60 Spreader



Accessories for Shindaiwa products can be found at:
www.shindaiwa-usa.com/products/accessories.aspx

PARTS LIST	2
PARTS LIST	3

PARTS LIST



NO.	PART NUMBER	QTY.	DESCRIPTION
1	P15862-1	1	Hopper Assembly
1A	P15270	1	+Hopper
2	P14454-1	1	+Shutoff Plate
3	P15377	2	+Shutoff Plate Guides
4	P14455-1	1	+Rate Cam & Chute Assembly
5	P14312-1	1	+Impeller Shaft Bearing
6	P15859-03	1	Frame Assembly
7	P15863	2	Drive & Free Turning Wheels
8	P15860	2	Axle Bushings
9	P14063	1	Axle Collar
10	P15027	1	Axle Gear
11	P14868-1	3	Gear Cover Clamps
12	P15012	2	Gear Cover
13	P15857	1	Impeller Assembly
14	P14625	1	+Impeller
15	P15856-07	1	+Impeller Shaft
16	P15028	1	+Gear Support
17	P14833	1	+Pinion Gear
18	P14022	2	Screen Clips
19	P14603-04	1	Hopper Screen
20	P15852-03	1	Handle Brace W/ Plug- LH.
21	P15853-03	1	Handle Brace W/ Plug- RH.
22	P15283-03	1	Handle Tube
23	P15264	2	Handle Grips
24	P13634-2	1	T-Handle Assembly
25	P15882	1	Control Knob & Wire Ass'y.
26	P14462	1	Control Knob Spring
27	P13643-1	1	Wire Retaining Clip
28	P15271	1	Hopper Plug
29	33117	1	Agitator
30	P15858-07	1	Axle
31	P15864	1	Parts Package
32	P14606-1	1	Hopper Cover
33	P16234	1	Hopper Label