shindaiwa®

Operator's Manual 491s Chainsaw

WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

WARNING



Read and understand all provided literature before use. Failure to do so could result in serious injury.

TABLE OF CONTENTS

TABLE OF CONTENTS

Introduction	3
Servicing Information	4
Parts and Serial Number	4
Service	4
Consumer Product Support	4
Product Registration	4
Product Registration	4
Safety	5
Manual Safety Symbols and Important Information	5
International Symbols	6
Personal Condition and Safety Equipment	8
Personal Condition and Safety Equipment Rules for Safe Operation	12
Correct Use of Chain Brake	13
(Exhaust & Evaporative) CARB and EPA Emissions Control Information	19
CARB and EPA Emissions Control Information	19
Description	20
Contents	
Preparation for Use	
Operation	
Chain Lubricant	31
Starting Cold Engine	31
Starting Warm Engine	33
Running	34
Stopping	35
Checking Chain Tension	35
Chain Lubrication Test	
Cutting Instructions	
Chain And Guide Bar Combination	40
Guide Bar	
Saw Chain	
Maintenance	
Skill Levels	
Maintenance Intervals	
Carburetor Adjustment	
Air Filter	
Spark Plug	46
Check Fuel System	47
Fuel Filter	47
Automatic Oiler.	
Oil Filter	
Guide Bar	
Sprocket	
Cooling System Cleaning	49
Spark Arrester Muffler	50
Spark Arrester Screen	50
Setting the Saw Chain	51
Troubleshooting	54
Storage	56
Storage After Use	56
Specifications	
Product Registration	
	00

shindaiwa[®]—

X7503312606 © 02/24 ECHO Incorporated

INTRODUCTION

Specifications, descriptions, and illustrative material in this literature are as accurate as possible. Specifications are subject to change without notice. Illustrations might include optional equipment and accessories, and might not include all standard equipment. Your equipment might appear slightly different than pictured equipment.



Read and understand all provided literature. Literature contains specifications and information for safety, operation, maintenance, storage, and assembly specific to this product. Scan QR codes for more information.



For additional literature, including safety manuals where applicable, or questions regarding terms used in this manual, visit:

shindaiwa

https://www.echo-usa.com/manuals



OR

https://www.shindaiwa-usa.com/manuals



SERVICING INFORMATION

Parts and Serial Number

Genuine Shindaiwa Parts and Assemblies for your Shindaiwa products are available only from an Authorized Shindaiwa Dealer. When you do need to buy parts **always** have



the Model Number and Serial Number of the unit with you. For future reference, write them in the space provided below.

Model No. Serial No.

Service

Service of this product during the warranty period must be performed by an Authorized Shindaiwa Service Dealer. For the name and address of the Authorized Shindaiwa Service Dealer nearest you, ask your retailer or call: 1-877-986-7783. Dealer information is also available on www.shindaiwa-usa.com. When presenting your unit for Warranty service/repairs, proof of purchase is required.

Consumer Product Support

If you require assistance or have questions concerning the application, operation or maintenance of this product you may call the Shindaiwa Consumer Product Support Department at 1-877-986-7783 from 8:00 am to 5:00 pm (Central Standard Time) Monday through Friday. Before calling, please know the model and serial number of your unit.

Product Registration

To ensure trouble free warranty coverage it is important that you register your Shindaiwa equipment on-line at www.shindaiwa-usa.com or by filling out the product registration sheet included in this manual. Registering your product confirms your warranty coverage and provides a direct link between you and ECHO if we find it necessary to contact you.

Additional Literature

4

In addition to finding information online, information is available from your Authorized Shindaiwa Service Dealer, or by contacting ECHO Incorporated, 400 Oakwood Road, Lake Zurich, IL 60047, 1-800-432-ECHO (3246).



X7503312606 © 02/24 ECHO Incorporated

SAFETY

Manual Safety Symbols and Important Information

Throughout this manual and on the product itself, you will find safety alerts and helpful, informational messages preceded by symbols or key words. The following is an explanation of those symbols and key words and what they mean to you.

DANGER

The safety alert symbol accompanied by the word "DANGER" calls attention to an act or condition which WILL lead to serious personal injury or death if not avoided.

WARNING

The safety alert symbol accompanied by the word "WARNING" calls attention to an act or condition which CAN lead to serious personal injury or death if not avoided.

ACAUTION

The safety alert symbol accompanied by the word "CAUTION" calls attention to an act or condition which might lead to minor or moderate personal injury if not avoided.

NOTICE

The enclosed message provides information necessary for the protection of the unit.

Note: This enclosed message provides tips for use, care and maintenance of the unit.



CIRCLE AND SLASH SYMBOL

This symbol means the specific action shown is prohibited. Ignoring these prohibitions can result in serious or fatal injury.

International Symbols

Symbol	Description	Symbol	Description
	WARNING! Read and follow all safety precautions in the instruction manual. Failure to follow instructions could result in serious personal injury.	Η	Carburetor Adjustment - High Speed Mixture
	Wear Eye, Ear, and Head Protection.	Т	Carburetor Adjustment - Idle Speed
	Tip contact may cause the guide bar to move suddenly upward and backward, which may cause serious injury.	L	Carburetor Adjustment - Low Speed Mixture
	Contact of the guide bar tip with any object should be avoided.	Max xx°	Measured maximum kickback value, without brake, for approved bar and chain combinations.
	Both of the operator's hands must be used to operate the chainsaw.	I I I I I I I I I I I I I I I I I I I	Fuel and Oil Mixture
	Hot Surface		Chain Oil Fill

shindaiwa —

Symbol	Description	Symbol	Description
٥ ٦	Chain Brake Operation		Chain Oiler Adjustment
~ †	Choke Control "COLD START" Position (Choke Closed) Choke Control "RUN" Position (Choke Open)		Purge Bulb
Ť	Decompression Device	STOP STOP	STOP / Momentary STOP Switch

Note: Not all symbols will appear on your unit.



Personal Condition and Safety Equipment

WARNING

Cancer and Reproductive Harm www.P65Warnings.ca.gov





The muffler or catalytic muffler and surrounding cover may become extremely hot. Always keep clear of exhaust and muffler area, otherwise serious personal injury might occur.

WARNING

Users of this product risk injury to themselves and others if the unit is used improperly and/or safety precautions are not followed. Proper clothing and safety gear must be worn when operating unit.

Physical Condition

Your judgment and physical dexterity may not be good:

- If you are tired or sick
- · If you are taking medication
- If you have taken alcohol or drugs

Operate unit only if you are physically and mentally well.

Eye Protection

WARNING

- Eye protection that meets ANSI Z87.1 or CE requirements must be worn whenever you operate the unit.
- For additional safety, a full-face shield can be worn over safety glasses or goggles to provide protection from sharp branches or flying debris.

shindaiwa[®]-

491

Hand Protection

Wear sturdy, no-slip, rubber work gloves to improve your grip on the handles. Gloves also provide protection against cuts and scratches, cold environments, and reduce the transmission of machine vibration to your hands.

Hearing and Ear Protection

ECHO recommends wearing personal protective equipment whenever unit is used.

Breathing Protection

Operators who are sensitive to dust or other common airborne allergens may need to wear a dust mask to prevent inhaling these materials while operating unit. Dust masks can provide protection against dust, plant debris, and other plant matter such as pollen. Make sure the mask does not impair your vision, and replace the mask as needed to prevent air restrictions.

Proper Clothing

Wear snug-fitting, durable clothing:

- · Pants should have long legs, shirts should have long sleeves.
- · DO NOT WEAR SHORTS.
- DO NOT WEAR TIES, SCARVES, JEWELRY, or clothing with loose or hanging items that could become entangled in moving parts or surrounding growth.
- · Keep clothing buttoned or zipped, and keep shirt tails tucked in.
- · Wear sturdy work shoes with nonskid rubber soles.
- · DO NOT WEAR OPEN TOED SHOES.
- DO NOT OPERATE UNIT WITH BARE FEET.

Keep long hair away from engine and air intake. Retain hair with cap or net.

Heavy protective clothing can increase operator fatigue, which may lead to heat stroke. Schedule heavy work for early morning or late afternoon hours when temperatures are cooler.

WARNING

The components of this machine generate an electromagnetic field during operation, which can interfere with some pacemakers. To reduce the risk of serious or fatal injury, persons with pacemakers should consult with their physician and the pacemaker manufacturer before operating this machine. In the absence of such information, ECHO <u>does not</u> <u>recommend</u> the use of this machine by anyone who has a pacemaker.

Extended Operation and Extreme Conditions

Prolonged exposure to cold and/or vibration can result in injury. Read and follow all safety and operation instructions to minimize risk of injury. Failure to follow instructions can result in painful wrist/hand/arm injuries.

It is believed that a condition called Raynaud's Phenomenon, which affects the fingers of certain individuals, may be brought about by exposure to vibration and cold. Exposure to vibration and cold may cause tingling and burning sensations, followed by loss of color and numbness in the fingers. The following precautions are strongly recommended, because the minimum exposure, which might trigger the ailment, is unknown.

- Keep your body warm, especially the head, neck, feet, ankles, hands, and wrists.
- Maintain good blood circulation by performing vigorous arm exercises during frequent work breaks, and also by not smoking.
- Limit the hours of operation. Try to fill each day with jobs where operating the unit or other hand-held power equipment is not required.
- If you experience discomfort, redness, and swelling of the fingers followed by whitening and loss of feeling, consult your physician before further exposing yourself to cold and vibration.

shindaiwa[®]

Repetitive Stress Injuries (RSI)

It is believed that overusing the muscles and tendons of the fingers, hands, arms, and shoulders may cause soreness, swelling, numbness, weakness, and extreme pain in those areas. Certain repetitive hand activities may put you at a high risk for developing a Repetitive Stress Injury (RSI). An extreme RSI condition is Carpal Tunnel Syndrome (CTS), which could occur when your wrist swells and squeezes a vital nerve that runs through the area. Some believe that prolonged exposure to vibration may contribute to CTS. CTS can cause severe pain for months or even years.

To reduce the risk of RSI/CTS, do the following

- Avoid using your wrist in a bent, extended, or twisted position. Instead try to maintain a straight wrist position. Also, when grasping, use your whole hand, not just the thumb and index finger.
- Take periodic breaks to minimize repetition and rest your hands.
- Reduce the speed and force with which you do the repetitive movement.
- Do exercises to strengthen the hand and arm muscles.



 Immediately stop using all power equipment and consult a doctor if you feel tingling, numbness, or pain in the fingers, hands, wrists, or arms. The sooner RSI/CTS is diagnosed, the more likely permanent nerve and muscle damage can be prevented.

A DANGER

All over head electrical conductors and communications wires can have electricity flow with high voltages. This unit is not insulated against electrical current. Never touch wires directly or indirectly, otherwise serious injury or death can result.

A DANGER

Do not operate this product indoors or in inadequately ventilated areas. Engine exhaust contains poisonous emissions and can cause serious injury or death.

X7503312606





Rules for Safe Operation

Kickback Safety Precautions for Chainsaw Users



KICKBACK may occur when the nose or tip of the guide bar touches an object, or when the wood closes in and pinches the saw chain in the cut.

Tip contact in some cases may cause a lightning fast reverse REACTION, kicking the guide bar up and back towards the operator. Pinching the saw chain along the top of the guide bar may push the guide bar rapidly back towards the operator. Either of these reactions may cause you to lose control of the saw which could result in serious personal injury.

The optional Kick GuardTM device is not installed on the guide bar when you purchase your chainsaw. The optional Kick Guard can be used in a majority of cutting operations, and is especially recommended for beginners, homeowners, or chainsaw novices. Most cutting operations can be accomplished with the optional Kick Guard in place.





Do not rely exclusively upon the safety devices built into your saw. As a chainsaw user, you should take several steps to keep your cutting jobs free from accident or injury.

shindaiwa[®]

 With a basic understanding of kickback, you can reduce or eliminate the element of surprise. Sudden surprise contributes to accidents.





© 02/24 ECHO Incorporated

X7503312606

- Keep a good firm grip on the saw with both hands, the right hand on the rear handle, and the left hand on the front handle, when the engine is running. Use a firm grip with thumbs and fingers encircling the chainsaw handles. A firm grip will help you reduce kickback and maintain control of the saw. Don't let go.
- Make sure that the area in which you are cutting is free from obstructions. Do not let the nose of the guide bar contact a log, branch, or any other obstruction which could be hit while you are operating the saw.



- 4. Cut at high engine speeds.
- 5. Do not overreach or cut above shoulder height.
- 6. Follow manufacturer's sharpening and maintenance instructions for the saw chain.
- 7. Only use replacement bars and chains specified by the manufacturer or the equivalent.

Shindaiwa

Correct Use of Chain Brake

Chain Brake Operation

- Set the lever in the unlocked position before starting to cut.
- If the brake is tripped by kickback reaction, the chain will stop immediately. Release the throttle to avoid possible damage to the engine or clutch.
- Do not attempt to operate the engine with the brake locked.





Testing the Brake

- Start the engine on a solid level surface and run at a fast idle until warm.
- Hold the saw firmly by the handles and accelerate the engine to a fast idle.
- Slowly operate the chain brake lever while holding the saw firmly on the ground. When the brake lever trips, the chain should stop. Immediately release the throttle trigger.

NOTICE

Do not allow the saw to tip forward in order to avoid damage to the chain.

WARNING

If the chain does not stop immediately, return the saw to your authorized dealer for repair.

Note:

- For practice, while cutting a small tree, push the lever forward to lock the brake.
- · Confirm that the brake works properly before each use.
- If the chain brake is clogged with wood chips, function of the brake may deteriorate. Always keep the device clean.
- Do not increase engine RPM while the chain brake is locked.

Do not use a bar and chain combination other than those specified in this manual.

For your own safety, do not remove the chain brake system.

The installation of a chain brake may be mandatory by law or as stipulated by insurance regulations in your area of operation. You should inquire through local government offices, your employer or your local dealer to ensure that your chainsaw conforms to the required safety standard.

Chain brakes have been designed and tested to comply with international safety standards as follows:

shindaiwa[®]

USA: ANSI Standard B175.1 Safety Requirement for chainsaws

Canada: CSA Standard Z62.1, Z62.3

491

WARNING

ANSI Standard B175.1 and CSA Z62.1.3 stipulate that the brake shall stop the chain 0.12 seconds at an engine speed of 13,500 RPM. It is the responsibility of the owner/ operator to ensure that the brake is serviced, adjusted and tested strictly in accordance with the instructions as detailed here in order to ensure that the brake performance is maintained in compliance with the Standards B175.1 and CSA 76213



Automatic Chain Brake

Kickback produced from the tip of the guide bar will trip the automatic chain brake. To make sure that the automatic chain brake operates properly, follow these steps:

- 1. Stop the engine.
- 2. Hold the saw with the guide bar approximately 35 cm (14 in.) above a wooden surface. Right hand should hold the rear handle, and left hand should hold the front handle.
- 3. Release the front handle and drop the end of the guide bar against the wooden surface.
- 4. The impact should lock the chain brake.

NOTICE

When checking the operation of the automatic chain brake, use a soft surface substance like wood to absorb the impact so the chain is not damaged.

Other Safety Precautions

- 1. Do not operate a chainsaw with one hand! Serious injury to the operator, helpers, bystanders, or any combination of these persons may result from one-handed operation. A chainsaw is intended for two-handed use.
- 2. Do not operate a chainsaw when you are fatigued.
- 3. Use safety footwear, snug-fitting clothing and protective gloves. Wear eye, hearing, and head protection devices.
- 4. Use caution when handling fuel. Mix and pour fuel outdoors where there are no sparks and flames. Slowly remove the fuel cap only after stopping the engine and allowing the chainsaw to cool. Do not smoke while fueling or mixing fuel. Move the chainsaw at least 10 feet (3 m) from the fueling point before starting the engine.
- 5. Do not allow other persons to be near the chainsaw when starting or cutting with the chainsaw. Keep bystanders and animals out of the work area.
- 6. Do not start cutting until you have a clear work area, secure footing, and a planned retreat path from the falling tree.
- 7. Keep all parts of your body away from the saw chain when the engine is running.
- 8. Before you start the engine, make sure that the saw chain is not contacting anything.
- 9. Carry the chainsaw with the engine stopped, the guide bar and saw chain to the rear, and the muffler away from your body.
- 10. Do not operate a chainsaw that is damaged, improperly adjusted, or not completely and securely assembled. Be sure that the saw chain stops moving when the throttle control trigger is released.
- 11. Shut off the engine before setting the chainsaw down.
- 12. Use extreme caution when cutting small size brush and saplings because slender material may catch the saw chain and be whipped toward you or pull you off balance.
- 13. When cutting a limb that is under tension, be alert for spring-back so that you will not be struck when the tension in the wood fibers is released.
- 14. Keep the handles dry, clean, and free of oil or fuel mixture.
- 15. Operate the chainsaw only in well ventilated areas.
- 16. Do not operate a chainsaw in a tree unless you have been specifically trained to do so.



- 17. All chainsaw service, other than items listed in the operator's manual maintenance instructions, should be performed by competent service personnel. For example, if improper tools are used to remove the flywheel or if an improper tool is used to hold the flywheel in order to remove the clutch, structural damage to the flywheel could occur and could subsequently cause the flywheel to burst.
- 18. When transporting your chainsaw, use the appropriate guide bar cover.
- 19. A spark arrester muffler approved to SAE Standard J335 is standard on this chainsaw to reduce the possibility of forest fires. Do not operate the chainsaw with a loose or defective muffler. Do not remove the spark arrester screen.
- 20. When using a chainsaw a fire extinguisher should be available.
- 21. When felling, keep at least two tree lengths between yourself and your fellow workers.
- 22. Follow instructions in your operator's manual for starting the chainsaw.
- 23. Never adjust the guide bar or saw chain with the engine operating.
- 24. When boring with the chainsaw, the initial cut should be introduced with the lower part of the nose (tip) until the hole is sufficiently large so as to introduce the entire nose (tip) of the guide bar. This technique should reduce the danger of kickback.
- 25. Allow your chainsaw to cool before refueling, and do not smoke while refueling.

WARNING

Chainsaws shall be used in accordance with the operating instructions and safety precautions listed in the operator's manual(s). It shall be the responsibility of the owner to see that such instructions and precautions are given to every operator who uses the saw.

WARNING

- During operation, the muffler or catalytic muffler and surrounding cover become hot.
- Never suspend the saw on a lanyard with the engine running.
- Always use the saw from the right-hand side of your body NEVER from the left side.
- Always wear proper safety clothing to protect your lower body from sharp saw chain and hot muffler.

 Always keep exhaust area clear of flammable debris during transportation or when storing, otherwise serious property damage or personal injury may result.



Moving parts can amputate fingers or cause severe injuries. Keep hands, clothing and loose objects away from all openings.

- ALWAYS stop engine, disconnect spark plug, and make sure all moving parts have come to a complete stop before removing obstructions, clearing debris, or servicing unit.
- DO NOT start or operate unit unless all guards and protective covers are properly assembled to unit.
- NEVER reach into any opening while the engine is running. Moving parts may not be visible through openings.

WARNING

Using improper replacement components or removing safety devices may result in serious or fatal injury.

Periodically Check fuel system (fuel lines, vent, grommet, fuel tank, and fuel cap) for leaks especially if the unit is dropped. If damage or leaks are found, do not use unit, otherwise serious personal injury or property damage may occur. Have unit repaired by an authorized servicing dealer before using.

shindaiwa

EMISSION CONTROL (EXHAUST & EVAPORATIVE)

CARB and FPA Emissions Control Information

The emission control system for the engine is EM (engine modification) and, if the second to last character of the Engine Family on the Emission Control Information label (sample below) is "B", "C", "K", or "T", the emission control system is EM and TWC (3-way catalyst). The fuel tank/fuel



YAMABIKO CORP. MMM/YYYY

line emission control system is EVAP (evaporative emissions). Evaporative emissions for California models are only applicable to fuel tanks and fuel feed lines

An Emission Control Label is located on the engine. (This is an EXAMPLE ONLY, information on

label varies by engine FAMILY).

EMISSION CONTROL INFORMATION ENGINE FAMILY: CEHXS.0214KL DISPLACEMENT: 21.2cc EMISSION COMPLIANCE PERIOD: 300Hours THIS ENGINE. MEETS 2012 U.S. EPA EXH/EVP & CALIFORNIA EXH/EVP EMISSION REGULATIONS FOR S.O.R.E. REFER TO OWNER'S MANUAL FOR MAINTENANCE SPECIFICATIONS AND ADJUSTMENTS. YAMABIKO CORP. MMM/YYYY

Product Emission Durability (Emission Compliance Period)

The 50 or 300 hour emission compliance period is the time span selected by the manufacturer certifying the engine emissions output meets applicable emissions regulations, provided that approved maintenance procedures are followed as listed in the Maintenance Section of this manual.

DESCRIPTION

Locate the safety decal(s) or etching(s) on your unit. Make sure they are legible, and that you understand and follow the instructions. If any cannot be read, replacements can be ordered from your Shindaiwa dealer. Images shown below are for example only. Those on your unit might appear slightly different





shindaiwa[®]

- 1. Front handle for the left hand
- 2. Chain brake lever / front hand guard
- 3. Spark arrester muffler or spark arrester muffler with catalyst
- 4. Kick GuardTM (Optional)
- 5. Saw chain
- 6. Guide bar
- 7. Spiked bumper
- 8. Chain catcher
- 9. Chain tension adjuster
- 10. Chain brake / sprocket guard
- 11. Rear hand guard
- 12. Choke control knob
- 13. Air filter cover and knob
- 14. Spark plug
- 15. Throttle trigger lockout
- 16. Rear handle for the right hand
- 17. Throttle trigger
- 18. Ignition switch
- 19. Fuel tank cap
- 20. Starter handle
- 21. Oil tank cap
- 22. Cylinder cover

CHAINSAW TERMS

- 1. **FAST IDLE** Throttle setting that causes engine to operate at a faster speed for easier starting.
- THROTTLE LATCH Device that sets idle speed to fast idle when choke control is operated.
- 3. CHAIN BRAKE Stops the saw chain.
- 4. **DRIVE SPROCKET** Drives saw chain.
- 5. **CLUTCH** Turns drive sprocket when engine rpm is fast enough to provide the power needed for cutting.

CONTENTS

The product you purchased has been factory pre-assembled for your convenience. Due to packaging restrictions, some assembly may be necessary.

After opening the carton, check for damage. Immediately notify your retailer or dealer of damaged or missing parts. Use the contents list to check for missing parts.

- 1 Power head
- 1 Operator's manual
- 1 Warranty statement
- 1 Guide bar
- 1 Guide bar cover
- 1 Saw chain

Preparation for Use

WARNING

Saw chain is sharp! Always wear gloves when handling assembly, otherwise serious personal injury may result.

Note: The machine may be delivered with guide bar, and saw chain separated. Install guide bar, saw chain, and optional Kick GuardTM as follows.

Instructions to Install Optional Kick Guard to Bar

Tools Needed: Two 11 mm (7/16 in.) Wrenches.

For saws with Optional Kick Guard, P/N 2894901, and Symmetrical or Asymmetrical Low-Kick type (Double Guard) guide bars:

shindaiwa[®]

X7503312606

- Install bolt (A) in *rear* hole (B) of Kick Guard and through front hole (C) in guide bar.
- <u>IMPORTANT:</u> Dimple (D) in Kick Guard must engage recess (E) in guide bar.
- 3. Securely tighten nut (F) and bolt (A).

For saws with Optional Kick Guard, P/N 2894901, and Symmetrical or Asymmetrical Low-Kick type (Pro-Lite) guide bars:

- Install 8-32 bolt in *small* hole of Kick Guard and through *small* hole in center of bar nose.
- 2. **IMPORTANT:** Dimple in Kick Guard must engage recess in guide bar.
- 3. Securely tighten nut and bolt.

Guide Bar and Saw Chain Installation and Removal

shindaiwa

- Align the brake connector (B) on the sprocket guard cover (C) to the groove on the side of the brake lever (A) (Front hand guard).
- 2. Remove air filter cover and disconnect spark plug lead.
- Move the chain brake lever (A) (Front hand guard) fully REARWARD (UNLOCK chain brake) to remove or install the sprocket guard cover (C).
- Remove sprocket guard cover nuts (D) and remove sprocket guard cover (C).







- 5. Remove guide bar and saw chain if necessary.
- Note: See "Maintenance and Care" section for guide bar/saw chain maintenance procedures.

 Mount guide bar on studs (E) and slide toward sprocket (F) to make saw chain installation easier. Install saw chain around sprocket (F) and guide bar. Make sure chain cutters are on top of guide bar and facing forward as shown.



 Install sprocket guard cover (C) over guide bar studs (E). Make sure chain tension adjuster pin (H) fits into the guide bar adjuster hole (G), and brake band (J) is positioned around clutch drum. Tighten sprocket guard nuts (D) finger tight.

shindaiwa[®]

- Turn saw over, and check brake band (J) for correct position on clutch drum. If brake band is not in place around drum, remove sprocket guard cover (C), and reinstall. Tighten sprocket guard nuts (D) finger tight.
- 9. Adjust saw chain tension, as instructed in "Adjusting Chain Tension".



WARNING

Improper sprocket guard assembly can result in serious injury, and will cause severe saw damage if unit is started. Never start or operate saw if brake band is not in place on clutch drum. Always check chain brake operation after replacing guard. Do not use saw if chain brake does not function properly.

Adjusting Chain Tension

NOTICE

Always loosen sprocket guard nuts before turning the chain tension adjuster, otherwise the sprocket guard and tensioner will be damaged.

- 1. Release the cylinder cover thumbscrew, and remove the cylinder cover. Remove spark plug lead.
- 2. Unlock chain brake and loosen sprocket guard nuts.



 Hold the bar nose up, and turn the adjuster screw (A) clockwise until chain contacts underside of the bar.



4. Tighten nuts with the bar nose held up.



NOTICE

shindaiwa[®]

Tighten guide bar nuts to 20-23 N•m (175-200 lbf•in). DO NOT over-tighten nuts. Damage to saw may result.

- 5. Pull the chain around the bar by hand. Loosen the adjustment if you feel tight spots.
- 6. Assemble components in reverse order.
- 7. Keep chain properly tensioned at all times.
- Note: All chains require frequent adjustments.



OPERATION

WARNING

Moving parts can amputate fingers or cause severe injuries. Keep hands, clothing and loose objects away from all openings. Always stop engine, disconnect spark plug, and make sure all moving parts have come to a complete stop before removing obstructions, clearing debris, or servicing unit.

WARNING

Engine exhaust IS HOT, and contains Carbon Monoxide (CO), a poison gas. Breathing CO can cause unconsciousness, serious injury, or death. Exhaust can cause serious burns. ALWAYS position unit so that exhaust is directed away from your face and body.

WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation. This unit is equipped with a spark arrester to prevent discharge of hot particles from the engine. Metal cutters can also create sparks if the cutter strikes rocks, metal, or other hard objects. Contact local fire authorities for laws or regulations regarding fire prevention requirements.

Fuel

WARNING

Diesel fuels and alternative fuels, such as E15 (15% ethanol), E85 (85% ethanol) or any fuels not meeting Shindaiwa requirements are NOT approved for use in Shindaiwa 2-stroke or Hybrid 4-stroke gasoline engines. Use of diesel or alternative fuels may cause performance problems, loss of power, overheating, fuel vapor lock, and unintended machine operation, including, but not limited to, improper clutch engagement. Diesel or alternative fuels may also cause premature deterioration of fuel lines, gaskets, carburetors and other engine components.

Fuel Requirements

Gasoline - Use fresh (purchased within the last 30 days from the pump) 89 Octane [R+M/2] (mid grade or higher) gasoline known to be good quality. Gasoline may contain up to 10% Ethanol (grain alcohol) or 15% MTBE (methyl tertiary-butyl ether). Gasoline containing methanol (wood alcohol) is **NOT** approved. Use of ECHO branded fuel is recommended to extend engine life in all air-cooled 2-stroke and 2/4-stroke hybrid engines.

Two Stroke Oil - A 2-stroke engine oil, such as Shindaiwa branded 2-stroke oils, meeting ISO-L-EGD (ISO/CD 13738) and J.A.S.O. FD Standards must be used. Shindaiwa branded 2-stroke oils meet these standards. Engine problems due to inadequate lubrication caused by failure to use an ISO-L-EGD (ISO/CD 13738) and J.A.S.O. M345-FD certified oil will void the 2-stroke engine warranty.

WARNING

2-Stroke engine oil contains petroleum distillates and other additives that may be harmful if swallowed. Heated oil can release vapors that can cause flash fire, or ignite with explosive force. Read and follow the oil manufacturer's instructions, and observe all safety warnings and precautions for handling flammable liquids. For more detailed safety and first aid information, visit www.echo-usa.com for a copy of the Material Safety Data Sheet.

- ♦ KEEP OUT OF REACH OF CHILDREN.
- If swallowed, do not induce vomiting. CALL PHYSICIAN OR A POISON CONTROL CENTER IMMEDIATELY.
- WEAR SAFETY GLASSES when mixing or handling.
- AVOID repeated or prolonged skin contact.
- AVOID inhaling oil mists or vapors.

NOTICE

Shindaiwa branded 2-stroke oils may be mixed at 50:1 ratio for application in all Shindaiwa engines sold in the past, regardless of ratio specified in those manuals.

shindaiwa[®]

Handling Fuel

A DANGER

Fuel is VERY flammable. Use extreme care when mixing, storing or handling, or serious personal injury may result.

- Use an approved fuel container.
- DO NOT smoke near fuel.
- DO NOT allow flames or sparks near fuel.
- Fuel tanks/cans may be under pressure. Always loosen fuel caps slowly allowing pressure to equalize.
- NEVER refuel a unit when the engine is HOT or RUNNING!
- DO NOT fill fuel tanks indoors. ALWAYS fill fuel tanks outdoors over bare ground.
- DO NOT overfill fuel tank. Wipe up spills immediately.
- Securely tighten fuel tank cap and close fuel container after refueling.
- Inspect for fuel leakage. If fuel leakage is found, do not start or operate unit until leakage is repaired.
- Use caution when handling fuel. Mix and pour fuel outdoors where there are no sparks and flames. Slowly remove the fuel cap only after stopping the engine and allowing the unit to cool. Do not smoke while fueling or mixing fuel. Move the unit at least 10 feet (3 m) from the fueling point before starting the engine.

DANGER

Gasoline vapor is heavier than air, and can travel along the ground to nearby sources of ignition such as electrical motors, pilot lights, and hot or running engines. Vapors ignited by an ignition source can flash back to the fuel container, resulting in an explosion, fire, serious or fatal injuries, and extensive property damage.

Shindaiwa

OPERATION

Mixing Instructions

- 1. Fill an approved fuel container with half of the required amount of gasoline.
- 2. Add the proper amount of engine oil to gasoline.
- 3. Close container and shake to mix oil with gasoline.
- 4. Add remaining gasoline, close fuel container, and remix.

Fuel to Oil Mix – 50:1 Ratio				
US		Metric		
Gas	Oil	Gas	Oil	
gal.	fl. oz.	L	СС	
1	2.6	5	100	
2	5.2	10	200	
5	13	25	500	

NOTICE

Spilled fuel is a leading cause of hydrocarbon emissions. Some states may require the use of automatic fuel shut-off containers to reduce fuel spillage.

After use

• Empty the fuel tank prior to storing the unit. Return unused fuel to an approved fuel storage container.

Storage - Fuel storage laws vary by locality. Contact your local government for the laws affecting your area. As a precaution, store fuel in an approved, airtight container. Store in a well-ventilated, unoccupied building, away from sparks and flames.

NOTICE

Stored fuel ages. Do not mix more fuel than you expect to use in thirty (30) days, ninety (90) days when a fuel stabilizer is added.

NOTICE

Stored 2-stroke fuel may separate. ALWAYS shake fuel container thoroughly before each use.

NOTICE

shindaiwa[®]

Used oil and gasoline, and soiled towels are hazardous waste materials. Disposal laws vary by locality.

Chain Lubricant

Proper lubrication of the chain while in operation reduces friction between the chain and the guide bar to a minimum and assures a longer service life.

Note: Cap indication - Fuel and oil tanks are indicated by the following illustrations

- Use bar and chain oil of high quality for this purpose.
- Do not use used or reclaimed oil to avoid various oiler problems.
- Use high quality bar and chain oil.



- Use bar and chain oil of the following grades:
 - SAE No. 30 in summer.
 - · SAE No. 10 in winter or when cutting resinous trees.
- When refueling, also refill chain oil.

Starting Cold Engine



- After choke control knob is pulled and then knob is returned to original position, throttle remains a little open (fast idle latch condition).
- The chain will attempt to move when engine is started with fast idle throttle latch engaged.
- Do not start engine before chain brake is locked.
- Make sure the bar and chain are free from any obstruction when starting the chainsaw.

- After starting the engine, immediately squeeze and then release throttle trigger for disengaging throttle latch and returning engine to idle, and pull front hand guard towards the operator immediately.
- Never use fast idle throttle latch for cutting. Use the fast idle throttle latch only in starting.
- Use the chain brake only in starting or in emergencies.

OPERATION

- 1. Move chain brake lever fully FORWARD to LOCK chain brake before starting.
- 2. Fill the fuel tank with fuel mixture. Do not fill fuel above the shoulder level of fuel tank.
- 3. Fill the chain oil tank with lubricant. Do not over fill.
- 4. Move ignition switch UP to "I" position.
- Pull choke control knob all the way OUT (CLOSED []~] choke position).
- Securely hold the chainsaw as shown and pull starter handle several times until first firing sound.
- Note: Do not pull starter rope out to the maximum possible position. Do not allow recoil handle to snap back



against the casing. If engine does not start after 5 pulls, repeat instructions.

shindaiwa⁻

- 7. Push choke control knob all the way in.
- 8. Pull starter handle again to start the engine.
- When engine starts, immediately squeeze and release throttle trigger for disengaging throttle latch and to return engine to idle. Pull front hand guard towards the operator immediately (Chain brake unlocked position).



Starting Warm Engine



Make sure the bar and chain are free from any obstruction when starting the chainsaw.

- 1. Move chain brake lever fully FORWARD to LOCK chain brake before starting.
- 2. Confirm there is fuel and chain oil in the tanks.
- Move ignition switch to "I" position.

- 4. Securely hold the chainsaw as shown and pull starter handle.
- Note: Do not pull starter rope out to the maximum possible position. Do not allow recoil handle to snap back against the casing. If engine does not start after 5 pulls, repeat instructions.
- 5. Choke may be used if necessary, but after first starting sound, squeeze throttle trigger to release choke and return engine to idle.
- Note: If engine does not start after 5 pulls, use cold start procedure.
- Note: Do not increase engine speed while chain brake is locked. Severe brake damage can result.



OPERATION

 After starting the engine, pull front hand guard towards the operator immediately. (Chain brake unlocked position).



Running

WARNING

The saw chain should not move at idle, otherwise serious personal injury may result.

- Note: If saw chain moves adjust carburetor according to "Carburetor Adjustment" instructions in this manual, or see your dealer.
- 1. After engine starts, allow it to return to idle and warm up before using.

shindaiwa[®]-

- Move chain brake lever fully REARWARD to UNLOCK chain brake.
- 3. Squeeze throttle trigger gradually and increase engine speed.
- The chain starts running when the engine reaches clutch engagement speed (see technical data page).
- 5. Confirm proper acceleration and lubrication of chain and bar.
- 6. Do not run the engine at high speed unnecessarily.
- Be sure that saw chain stops moving when throttle trigger is released.





34

Stopping

491

- 1. Release throttle trigger and allow engine to idle.
- Move ignition switch DOWN to "O" position.
- Note: If engine does not stop, pull choke control knob out fully to stop engine. Return the unit to your authorized dealer to check and repair stop switch before starting the engine again.





Do not operate with a loose chain.

Checking Chain Tension

Chain tension should be checked frequently during work and corrected as necessary.

Tension the chain as tight as possible, but so it can still be pulled easily along the bar by hand.

Chain Lubrication Test

Hold the chain just above a dry surface and open the throttle to half speed for 30 seconds.

A thin line of "thrown" oil should be seen on the dry surface.



Cutting Instructions

General



- This chainsaw is designed for cutting wood. Do not cut metal, plastic or any non-wood material.
- Wear suitable hearing protection such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.
- Do not let the tip of the bar touch anything while the engine is running. At cutting speed the chain is moving at a high rate of speed. Should the tip contact a limb or log while the chain is moving, the tip will be pushed upward with considerable force. This is known as kickback. Avoid it!





In all circumstances the operation of the chainsaw is a one-man job. It is difficult at times to take care for your own safety, so don't assume the responsibility for a helper as well. After you have learned the basic techniques of using the saw, your best aid will be your own good common sense.

shindaiwa[®]

The accepted way to hold the saw is to stand to the left of the saw with your left hand on the front handle and your right hand on the rear handle so you can operate the throttle trigger with your right index finger. Before attempting to fell a tree, cut some small logs or limbs. Become thoroughly familiar with the controls and the responses of the saw.


Start the engine, see that it is running properly. Squeeze the trigger to open the throttle wide open and start the cut. If the chain is properly sharpened, the cutting should be relatively effortless. It is not necessary to press down hard to make the saw cut. Pushing the saw too hard will slow the engine and cutting will actually be more difficult.



NOTICE

Sap from palm trees may corrode metal parts unless proper saw maintenance is performed. Make sure to clean metal parts from palm sap immediately after use.

- Remove sprocket guard. Clean wood chips and sawdust from guard and engine crankcase.
- Never use metal tools for cleaning which can scratch the metal paint and allow corrosion to develop.
- Clean sap accumulation from metal parts with cloth and warm water with soap.
- · Rinse with clean water and dry metal surfaces.
- Apply a light coating of engine or bar and chain oil to metal parts after they are cleaned.
- Install and properly tension guide bar and chain. Run engine for one minute alternating engine speed between full throttle for five seconds and idle for five seconds to coat metal parts with additional protective chain oil.

- Do not run a chainsaw not under cutting load at wide open throttle longer than five seconds or engine damage can occur.
- Keep chain properly tensioned during operation to prevent the chain from jumping out of the guide bar rail slot and damaging metal engine parts.

Felling the Tree

A WARNING

A falling tree can seriously damage anything it may hit - a car, a house, a fence, a power line, or another tree. There are ways to make a tree fall where you want it, so first decide where that is!

Before cutting, clear the area around the tree. You will need good footing while working and you should be able to work the saw without hitting any obstacles. Next, select a path of retreat. When the tree begins to fall you should retreat away from the direction of fall at a 45-degree angle and at least 3 m (10 feet) from the trunk to avoid the trunk kicking back over the stump.

Begin the cut on the side to which the tree is to fall. Cut a notch about 1/3 of the way into the tree. The position of this notch is important since the tree will try to fall "into" the notch. The felling cut is made on the side opposite the notch and at a level about 5 cm (2 in.) above the bottom of the notch. Do not try to cut through to the notch with the felling cut. The remaining wood between the notch cut and felling cut about 5 cm (2 in.) will act as a hinge when the tree falls, guiding it in the desired





direction. When the tree starts to fall, kill the engine, place the saw on the ground and make your retreat quickly.

shindaiwa

To fell big trees with a diameter exceeding twice the bar length, start the notching cuts from one side and draw the saw through to the other side of the notch. Start the back cut on one side of the tree, pivoting the saw through to form the desired hinge on that side. Then remove the saw for the second cut. Insert the saw in the first cut, very carefully so as not to cause kickback. The final



cut is made by drawing the saw forward in the cut to reach the hinge.

Limbing

Limbing a fallen tree is much the same as bucking. Never stand on the tree that you are limbing. When limbing, caution is the word. Be careful of the tip touching other limbs. Always use both hands.

Don't cut with the saw overhead or aligned vertically with your body. If the saw should kick back, you may not have enough control to prevent possible injury.





OPERATION

Bucking

Bucking is the sawing of a log or fallen tree into smaller pieces. There are a few basic rules which apply to all bucking operations.

- Keep both hands on the handles at all times.
- Support logs if possible.
- When cutting on a slope or hillside, always stand uphill.



Keep in mind that the wood is heavy and that it will bend and pinch the saw if improperly supported. The trunk will weaken at the point where you make the cut unless the tree is lying on perfectly flat ground or supported as shown. If you make the cut with the tree on the ground, don't let the saw's chain dig into the earth; it is harmful for the saw, and you stand a good chance of being struck by flying debris.

To cut the trunk, use the bucking and two-cut sequence shown. The first cut should be no deeper than one-third the trunk diameter.

Chain And Guide Bar Combination

The following combinations are recommended for model 491s.

Guide Bar		Saw Chain				
Length mm	Shindaiwa Part No.	Pitch mm (in.)	Туре	Links		
(in.)	Low-kickback		туре	LINKS		
406 (16)	S16F0AD3366	8.26 (0.325)	S20BPX66CQ	66		
457 (18)	S18F0AD3372	8.26 (0.325)	S20BPX72CQ	72		
508 (20)	S20F0AD3378	8.26 (0.325)	S20BPX78CQ	78		



Use of replacement saw chain and/or guide bar other than that specified, or operation without the optional Kick GuardTM in place, may cause severe kickback resulting in serious injury.



X7503312606

© 02/24 ECHO Incorporated

Only use saw chain designated as, "LOW-KICKBACK," that meets ANSI B175.1 or CSA Z62.1, .3 Standard when tested on the representative sample of chainsaws below 3.8 C.I.D., and Shindaiwa guide bar specified.

NOTICE

Chain and guide bar gauge size must be identical. Use Bar/Chain combinations shown in table above.

Guide Bar

(Low-kickback)

Replacement guide bars.

The following guide bars may be considered to have equivalent kickback energy.

- Sprocket nose guide bars of the same length and nose radius, same pitch and having the same number of teeth.
- Hard nose guide bars of the same length and nose radius as a sprocket nose bar.

Saw Chain

(Low-kickback)

Note: LOW KICKBACK SAW CHAIN meets the kickback performance requirements of ANSI B175.1 or CSA Z62.1, .3 (safety requirements for gasoline-powered chainsaws).

shindaiwa

Optional Kick GuardsTM:

2894902 for ECHO models CS-2511T- CS-400

2893202 for ECHO models CS-4510 - CS-800P

2894902 for Shindaiwa models 305s, 340s, 358TS, 402s

2893202 for Shindaiwa models 491s, 591, 600SX.

MAINTENANCE

WARNING

Moving parts can amputate fingers or cause severe injuries. Keep hands, clothing and loose objects away from all openings. Always stop engine, disconnect spark plug, and make sure all moving parts have come to a complete stop before removing obstructions, clearing debris, or servicing unit. Allow the unit to cool before performing maintenance or adjustments. Wear gloves to protect hands from sharp edges and hot surfaces.

WARNING

Operating a poorly maintained unit can result in serious injuries to operator or bystanders. Always follow all maintenance instructions as written, otherwise serious personal injury can result.

Your unit is designed to provide many hours of trouble free service. Regular scheduled maintenance will help your unit achieve that goal. If you are unsure or are not equipped with the necessary tools, we recommend that you take your unit to a Servicing Dealer for maintenance. To help you decide whether you want to DO-IT-YOURSELF or have the Dealer do it, each maintenance task has been graded. If the task is not listed, see your Dealer for repairs.

NOTICE

The use of emission control components other than those specifically designed for this unit is a violation of federal law.

Skill Levels

Level 1 = Easy to do. Common tools may be required.

- Level 2 = Moderate difficulty. Some specialized tools may be required.
- Level 3 = See your dealer.

Click HERE or go to http://www.echo-usa.com/products/maintenance-kit

or

HERE https://www.shindaiwa-usa.com/you-can.aspx



491

X7503312606

© 02/24 ECHO Incorporated

Maintenance Intervals



Units equipped with a Momentary STOP Switch automatically return to RUN position. Engine can start unintentionally. Always remove spark plug lead from spark plug before assembling or performing maintenance procedures, otherwise serious personal injury can result.

COMPONENT OR SYSTEM	MAINTENANCE PROCEDURE	REQUIRED SKILL LEVEL
Daily Or Before Use		
Air Filter	Inspect / clean *	1
Automatic Oiler	Inspect / adjust	1
Oil Filter	Inspect	1
Fuel System	Inspect	1
Guide Bar and Sprocket Nose	Inspect / clean *	1
Saw Chain	Inspect / sharpen / replace / tensioning *	2
Sprocket	Inspect / replace *	2
Cooling System	Inspect / clean	2
Recoil Starter Rope	Inspect / clean *	1
Screws / Nuts / Bolts	Inspect / tighten / replace *	1
Every Refuel		
Fuel System	Inspect	1
Guide Bar and Sprocket Nose	Inspect	1
3 Months		
Air Filter	Replace *	1
Oil Filter	Inspect / replace *	1
Fuel Filter	Inspect *	1
Fuel Cap Gasket	Inspect *	1
Spark Plug	Inspect / clean / replace *	1
Muffler Spark Arrester	Inspect / clean / replace *	2



COMPONENT OR SYSTEM	MAINTENANCE PROCEDURE	REQUIRED SKILL LEVEL	
Cylinder Exhaust Port	Inspect / clean / de-carbon	2	
Yearly			
Fuel Filter	Inspect / replace *	1	
Fuel Cap Gasket	Replace *	1	

IMPORTANT NOTE - Time intervals shown are maximum. Actual use and your experience will determine the frequency of required maintenance.

MAINTENANCE PROCEDURE NOTES:

* Replacement is recommended based on the finding of damage or wear during inspection.

shindaiwa[®]-

Carburetor Adjustment

Every unit is run at the factory and the carburetor is set in compliance with emission regulations. In addition, the carburetor is equipped with "H" (High Speed) and "L" (Low Speed) needle adjustment limiters that prevent settings outside acceptable limits.

Engine Break-In

New engines must be operated a minimum duration of two tanks of fuel break-in before carburetor adjustments can be made. During the break-in period your engine performance will increase and exhaust emissions will stabilize. Idle speed can be adjusted as required.





High Altitude Operation

This engine has been factory adjusted to maintain satisfactory starting and durability performance up to 335 m (1,100 ft.) above sea level (ASL) (96.0 kPa). To maintain proper engine operation above 335 m (1,100 ft.) ASL the carburetor <u>might</u> need to be adjusted by an authorized service dealer.

NOTICE

If the engine is adjusted for operation above 335 m (1,100 ft.) ASL, the carburetor must be readjusted when operating the engine below 335 m (1,100 ft.) ASL, otherwise severe engine damage can result.

- 1. Before adjusting carburetor clean or replace air filter and muffler spark arrester screen.
- 2. Make sure the bar and chain are properly adjusted.
- 3. Start engine and run several minutes to bring to operating temperature. Flash choke twice during warm-up to clear any air from the fuel system.
- Stop engine. Turn "H" High Speed needle counterclockwise (CCW) to stop. Turn "L" Low Speed needle midway between full clockwise (CW) stop and CCW stop.
- 5. Idle Speed Adjustment:
 - Start engine, turn Idle speed adjustment screw "T" CW until the saw chain begins to move, then turn screw out CCW until the saw chain stops moving. Turn screw out, CCW, an additional 1/4 turn.

WARNING

When carburetor adjustment is completed, the saw chain should not move at idle, otherwise serious personal injury can result.

- 6. Accelerate to full throttle for two to three seconds to clear any excess fuel in the engine, then return to idle. Accelerate engine to full throttle to check for smooth transition from idle to high speed. If engine hesitates turn "L" needle CCW 1/8 turn and repeat acceleration. Continue adjustment until smooth acceleration results.
- Check idle speed and reset if necessary as described in item 5. If a tachometer is available idle speed should be set to value listed on specifications page.

When starting, idling adjustment speed should be adjusted to prevent the saw chain from moving. When you experience trouble with the carburetor, contact your dealer.

Air Filter

- 1. Check before every use.
- 2. CLOSE choke (
- Turn air filter cover knob (A) counterclockwise by hand and remove air filter cover (B) and air filter (C).
- 4. Lightly brush dust off air filter, or clean with compressed air, or replace the air filter.
- 5. Re-install air filter (C) and air filter cover (B).
- 6. Turn air filter cover knob (A) clockwise until hand tight.

Spark Plug

- · Check periodically.
- The standard spark gap is 0.65 mm (0.026 in.).
- Fastening torque: 15-17 N•m (130-150 in•lbf).
- Remove air filter cover (B) and remove spark plug (D).
- 2. Correct the spark gap if it is wider or narrower than the standard gap.
- 3. Re-install spark plug (D) and air filter cover (B).
- 4. Turn air filter cover knob (A) clockwise until hand tight.

Check Fuel System

- Check before every use.
- After refueling, make sure fuel does not leak from around fuel pipe, fuel grommet or fuel tank cap.

shindajwa[®]-





X7503312606

© 02/24 ECHO Incorporated

• In case of fuel leakage there is a danger of fire. Stop using the machine immediately and request your dealer to inspect or replace.

Fuel Filter

- · Check periodically.
- Do not allow dust to enter fuel tank.
- A clogged filter (A) will cause difficulty in starting engine or abnormalities in engine performance.
- 1. Pull filter out through gas port, and inspect filter.





Do not damage fuel line while removing fuel filter from tank.

- 2. When the filter is dirty, replace it as follows:
- 3. Do not remove the wire coil clamp to remove the fuel filter. Pinch the fuel filter with the fingers on one hand and the fuel line with the other hand. Pull and twist slightly to separate.
- 4. Install the new filter with the reverse action.
- 5. When the inside of the fuel tank is dirty, rinse the tank out with gasoline to clean it.
- Note: Federal EPA regulations require all model year 2012 and later gasoline powered engines produced for sale in the United States to be equipped with a special low permeation fuel supply hose between the carburetor and fuel tank. When servicing model year 2012 and later equipment, only fuel supply hoses certified by EPA can be used to replace the original equipment supply hose. Fines up to \$37,500 may be enforced for using an un-certified replacement part.

Automatic Oiler

- The discharge volume of the automatic oiler is adjusted to approximately 7 mL/min at 7000 r/ min, prior to shipment from factory.
- Always check oil discharge when in use.





MAINTENANCE

- Turn adjusting screw counterclockwise to increase oil volume, clockwise to decrease oil volume. When the screw touches stopper and stops, this position indicates maximum discharge volume. (16.5 mL/min at 7000 r/ min).
- Do not turn the adjusting screw beyond the maximum or minimum limit of volume adjustment.

Oil Filter

- Check periodically.
- Do not allow dust to enter into oil tank.
- A clogged oil filter will affect the normal lubricating system.
- 1. Pull filter out through oil port, and inspect filter.
- 2. If the filter is dirty, wash it in gasoline or replace it as follows:
- 3. Do not remove the wire coil clamp to remove the filter. Pinch the filter with the fingers on one hand and the line with the other hand. Pull and twist slightly to separate.
- 4. Install the new filter with the reverse action.
- 5. When the inside of the tank gets dirty, rinse the tank out with gasoline to clean it.

shindaiwa[®]

Guide Bar

- 1. Clean before using.
- Clean the groove of the guide bar (A) with a small screwdriver.
- 3. Clean oil holes (B) with a wire.
- 4. Invert guide bar periodically.
- 5. Clean the guide bar mount area before installing the guide bar.



Sprocket

- A damaged sprocket will cause premature damage or wear of saw chain.
- When the sprocket has worn 0.5 mm (0.020 in.) or more, replace it.
- Check sprocket when you install new chain. Replace it if worn.





Some tree sap and resins are corrosive. Thoroughly wash the guide bar and sprocket areas after each use, then coat metal parts with light oil.

Cooling System Cleaning

- · Check periodically.
- Clogged fins will result in poor engine cooling.
- 1. Remove air filter cover, cylinder cover, and starter.
- 2. Use compressed air or wooden tool to remove dirt and dust from between fins to let cooling air pass easily.

Spark Arrester Muffler



- The spark arrester muffler controls the exhaust noise and prevents hot, glowing particles of carbon from leaving the muffler.
- Make sure the spark arrester screen is in good repair and properly seated in the muffler.
- Certain internal combustion engines operated on forest, brush, and/or grass-covered areas in the states of Washington, Oregon, Idaho, California, Minnesota, New Jersey and Maine, are required to be equipped with a spark arrester.

MAINTENANCE

This requirement also applies to all U.S. Forest Service lands. In some of these areas, the spark arrester system must be certified per USDA Forest Service Regulation SAE J335.

Check with your local or state authorities for specific regulations in your area. Failure to follow these requirements is a violation of the law.

Spark Arrester Screen

NOTICE

Carbon deposits in muffler will cause drop in engine output and overheating. Spark arrester screen must be checked periodically.

- 1. Remove air filter cover and remove spark plug lead.
- 2. Remove spark arrester cover (A) and screen (B) from muffler (C) body.
- 3. Clean carbon deposits from muffler components.
- 4. Replace screen if it is cracked, or has holes burned through.



- 5. Assemble components in reverse order.
- Note: When cleaning carbon deposit, be careful not to damage the catalytic element inside muffler.

Setting the Saw Chain



Important points for proper maintenance of saw chain:

- Keep the cutters sharp at all times.
- Keep the left and the right cutters properly aligned.



X7503312606 © 02/24 ECHO Incorporated

- Note that blunt or irregular cutters will result in poor cutting performance, increased vibration of chains and premature breakage of the saw chain.
- Drive link serves to remove sawdust from the groove of the guide bar. Keep the lower edge of the drive link sharp where indicated.



Setting Saw Chain

- For setting saw chain, round file (3/16 in. diameter) and flat file are used.
- Push file as shown.



- Hold the file as shown.
- Place the depth gauge tool firmly on guide bar so that depth gauge protrudes. Then file top of depth gauge with the flat file until flat with top of the depth gauge tool.

shindaiwa

• One-fifth of the file diameter remains above cutter edge.

X7503312606

© 02/24 ECHO Incorporated





MAINTENANCE

• Be sure to round off the front edge of the depth gauge.



• Properly filed cutters are shown in illustration.

 When setting of the chain is finished, soak it in oil and wash away filings completely

before using.

- When chain has been filed on the bar, supply sufficient oil to it, move the chain slowly to wash away the filings before using again.
- If the chainsaw is operated with filings clogged in the groove, the saw chain and the guide bar will be damaged prematurely.
- If the saw chain becomes soiled with resin, for instance, clean it with kerosene and soak in it oil.



shindaiwa[®]-

To sharpen other chains, follow chain manufacturer's instructions.

X7503312606 © 02/24 ECHO Incorporated

Parallel

Depth gauge

491

TROUBLESHOOTING

ENGINE PROBLEM TROUBLESHOOTING CHART						
Problem	Check	Status	Cause	Remedy		
	Fuel at carburetor	No fuel at carburetor	Fuel strainer or fuel line obstructed	Clean or replace See your dealer		
		No fuel at cylinder	Carburetor	See your dealer		
				OPEN choke		
Engine starts hard	Fuel at cylinder	Muffler wet	Fuel mixture too rich	Clean or replace air filter		
or		with fuel	псп	Adjust carburetor		
				See your dealer		
Engine does not start	Spark at end of plug		STOP switch OFF - Electrical problem -	Turn switch to ON		
	wire		Interlock switch	See your dealer		
	Spark at	No spark	Incorrect gap - Covered with carbon - Fouled	Adjust to 0.65 mm (0.026 in.)		
	plug		with fuel - Plug defective	Clean or replace plug		
Engine	Air filter	Air filter dirty	Normal wear	Clean or replace		
runs, but dies	Fuel filter	Fuel filter dirty	Contaminants or residue in fuel	Replace filter or replace fuel		
or						
Engine does not accelerate properly	Fuel vent	Fuel vent plugged	Contaminated fuel	Clean or replace		

shindaiwa

TROUBLESHOOTING

ENGINE PROBLEM TROUBLESHOOTING CHART							
Problem	Check	Status	Cause	Remedy			
Engine	Spark plug	Plug dirty or worn	Normal wear	Clean and adjust or replace			
runs, but dies	Carburetor	Improper adjustment	Vibration	Adjust			
or Engine does not accelerate properly	Cooling system	Cooling system dirty or plugged	Extended operation in dirty or dusty locations	Clean			
	Spark arrester screen screen plugged		Normal wear	Replace			
Engine does not crank	Ν	I/A	Internal engine problem	See your dealer			

Fuel vapors are extremely flammable and can cause fire and/or explosion. Never test for ignition spark by grounding spark plug near cylinder plug hole, otherwise serious personal injury can result.

shindaiwa



STORAGE

Storage After Use



Units equipped with a Momentary STOP Switch automatically return to RUN position. Engine can start unintentionally. Always remove spark plug lead from spark plug before assembling or performing maintenance procedures. Serious personal injury can result.

- · Inspect and adjust every part of the chainsaw.
 - · Completely clean every part and repair if necessary.
 - · Apply thin coating of oil on metal parts to prevent rust.
- Remove chain and guide bar.
- Drain fuel tank completely. Press purge bulb six to seven times to remove remaining fuel from carburetor then drain the tank again. Close choke, start and run the engine until it stops due to lack of fuel.
- Allow engine to cool. Remove the spark plug lead from the spark plug. Remove the spark plug. Pour 7 cc (0.25 oz.) of fresh, clean, two-stroke engine oil into the cylinder through the spark plug hole.
- Store in a dry area, free from dust.

WARNING

Do not store in an enclosure where fuel fumes may accumulate or reach an open flame or spark.



Do not lend or rent your chainsaw without the Operator's Manual.

Note:

- For future reference, you should keep this Operator's Manual.
- If this Operator's Manual becomes illegible or is lost, please contact your dealer, or go to www.echo-usa.com.

SPECIFICATIONS

SPECIFICATIONS

Model	491s		
Length	395 mm (15.5 in.)		
Width	250 mm (9.8 in.)		
Height	290 mm (11.42 in.)		
Dry weight	4.8 kg (10.6 lb.) Without chain and guide bar		
Engine	Air-cooled two-stroke single cylinder		
Displacement	50.2 mL (3.06 cu. in.)		
Bore	44.0 mm (1.73 in.)		
Stroke	33.0 mm (1.30 in.)		
Compressions ratio	7.75:1		
Carburetor	Diaphragm type		
Spark plug	NGK BPMR8Y (Gap 0.65 mm [0.026 in.])		
Fuel tank capacity	490 mL (16.6 US. fl. oz.)		
Fuel	50:1		
Gasoline	Use 89 octane unleaded. Do not use fuel containing methyl alcohol, more than 10% ethyl alcohol or 15% MTBE. Do not use alternative fuels such as E-15 or E-85.		
Oil	ISO-L-EGD (ISO/CD 13738) and JASO M345- FD two-stroke, air-cooled engine oil.		
Oiling system	Adjustable automatic oiler		
Chain oil capacity	280 mL (9.5 US. fl. oz.)		
Starter system	Automatic rewind starter		
Clutch	Centrifugal type		
Sprocket type	Spur type, 6-tooth, 3/8 in. pitch		
Chain brake	Automatic band brake type		
Idle speed	2,800RPM		
Clutch engagement speed	3,900RPM		
Wide Open Throttle speed (W.O.T.)	11,500 RPM		
Chain tensioner	Side access system		

shindaiwa[®]-

© 02/24 ECHO Incorporated

X7503312606

Model	491s		
Guide bar	16 ,18, 20 in		
Saw chain	66CQ, 72CQ, 78CQ		
Standard features	Front hand guard, Rear hand guard, Anti- vibration device, Spiked bumper, Throttle control lockout, Chain catcher, Spark arrester muffler		

* Technical data subject to change without notice.

PRODUCT REGISTRATION

Thank you for choosing Shindaiwa Power Equipment

Please go to http://www.shindaiwa-usa.com to register your new product on-line. It's **FAST** and **EASY**! NOTE: your information will never be sold or misused by ECHO Incorporated. Registering your purchase enables us to contact you in the unlikely event of a service update or product recall, and verifies your ownership for warranty consideration.

If you do not have access to the Internet, you can complete the form below and mail to:

ECHO Incorporated, Product Registration, PO Box 1139, Lake Zurich, IL 60047.

${f Shindawa}^{\circ}$ product registration card $:$ tarjeta de registro $:$ carte d'enregistrement du produit	OPCIÓN POR INTERNET: Registrese en la pagina web y ahorre una estampliat. Le alefrarán sobre actualizaciones del producto y/o se le enviran información sobre actualizaciones del producto y/o se le enviran información sobre actualizaciones del producto sobre actualizacione actualizaciones del producto sobre actualizaciones del pro	Confidential: Information provided will not be shared or sold	Primary use of tool: Drofessional DHomeowner DRental Equip. Uso primario de la harramienta: Drofesional Dueño de casa Adquiler Usage principal : Drofesionnel DResidential DLocation Drovou with the receive periodic Shindaiwa producti information and secretal	offers by e-mail? Types Thoman of the two second se		Visito usted la pagina web Shindaiwa antes de comprar su producto?	What factor(s) most influenced your purchase? Derformance Drice Dealer Reliability Drior Experience Outling Econditionality	nfluenció más en su com Precio Experiencia Anterior Marros	Contraction annual Contraction and a co	
TRATION CARD : TAF	OPCIÓN POR INTERNET: Registrese en la pagina web y ahorre una estampliei. Le alertarán sobre actualizaciones de producto yuo se le envirar información sobre los nuevos pro- ductos Shindaiwa y las ofertas especiales. Simplemente visit www.shindaiwa-usa.com	ettre Carré S.V.P.	eur		State : Estado : Zip Code : Código Postal : Code Postal Province	Électronique	Date of Purchase : Fecha de la Compra : Date de l'achat	o : Lieu d'achat	vumber : Numero de Serie : No. c	a service update or product recall and ver contacto con usted en caso de cualquier ón de propiedad en caso de robo o pérdi
Idaiwa® product regist	ONLINE OPTION: Register online and save a stamp! You will be alerted of product updates and/or be sent new Shindahwa product information and special offers. Simply go to: www.shindalwa-usa.com	Please Print : Por Favor Enscriba Con Letra De Molde : En Lettre Carré S.V.P.	Purchaser's Name : Nombre del Comprador : Nom de l'acheteur	Address : Dirección : Adresse	City : Cludad : Ville State : Estado : Zip Province	E-Mail Address : Dirección De Correo Electrónico : Courrier Électronique	Phone Number : Número De Teléfono : Téléphone Date	Where Purchased : Nombre del Almacén donde fue Comprado : Lieu d'achat	Model Number : Numero del Modelo: No. de modéle Serial Number : Numero de Serie : No. de série	Registering your purchase enables us to contract you in the unitlety event of a service update or product recail and vertifies your events of the event of loss. Et register as compare ones permite easies are contactor one stated en case devaluer eventio covers et ayors of thempo de axorolo of a revocación red producty y vertificación, de propleadat en traso de valoure eventio events of the event of the evention of a revocación red producty y vertificación, de propleadat en traso de valoure eventio covers et ayors of the evention of a revocación red producty y vertificación, de propleadat en traso de valoure eventio.

shindaiwa[®]

X7503312606 © 02/24 ECHO Incorporated

NOTES



C68415001001 - C68415999999



ECHO INCORPORATED

400 Oakwood Road Lake Zurich, IL 60047 www.shindaiwa-usa.com